



Touchscreen Product Cleaning Guide

Applicable models:

- StealthTouch series
- Stealth S-LINE series
- CarisTouch series
- Touch monitor series
- DASH Tablet Series

Cleaning and Disinfection Directions:

Before cleaning, please make sure the touch terminal is in one of the following states:

1. System is powered off, or
2. CleanMe Mode is turned on (only available on model CT18 and CT22)

Recommended Cleaning Solutions:

- Alcohol Based Solution (e.g. Isopropyl 70% Alcohol)
- Bleach Based Solution (diluted to 10% Bleach)

Avoid spraying cleaning solution directly onto the touchscreen or monitor. Always spray cleaning solution onto a soft cloth or towel before cleaning the surface of touchscreen or bezel. Avoid using any non-diluted bleach or chemical.

StealthTouch/Stealth S-LINE/Touch monitor



CarisTouch series



For further assistance, email support@pioneersolution.com or call 909-468-9757, option 2.